


RESET

AUX



ICST

R6

R4

Digital
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28

L100V1000

Analog
0
1
2
3
4
5

Power GND
VCC
GND
VCC
GND
Reset

SDA
SCL
A0
A1
GND

LE OLYMPIA

BATT